

FilterManagement

With the inventory management system, the operator can enter up to two filter part numbers per sensor along with in-stock quantity, quantity used per change out, and minimum in stock quantity. When replacement filters are received, the operator can add the replacement amount to the in-stock quantity of each part number.




MULTIPLE PART NUMBER PER SENSOR

During the initial setup, the operator can assign up to two part numbers to a specific sensor. The operator also enters the required quantity per change out and selects which email group to notify when the filters are replaced.



MULTIPLE PART NUMBER PER SENSOR

After a sensor exceeds the Replace Pressure Setpoint, a notification will appear at the lower left side of the screen alerting the operator to reset the filter chamber after the filters have been replaced.



REPLACEMENT RESET

The replacement reset screen is the summary of the part numbers and quantities being consumed and the current in stock quantity. If the in-stock quantity falls below the minimum set point, an email notification will be sent to the selected group when the reset procedure is complete.

Example Email Notification with Screenshot of Inventory Level

Example Email Notification with Screenshot of Inventory Level